

1. Required angle brackets



2. Mount the small bracket



3. Top view



4. Mount the big bracket on the rear side



5. Rear view



6. Remove the pre-installed ATX bracket from the chassis



7. Install the PSU into the chassis and fix it with the holes marked in red.



8. Fix the PSU with two additional screws in the rear (marked spots)



9. Done!