


Installation of slim-size ITX mainboard & 3.5" HDD (optional MK-35DV will be needed)


1. Open the chassis and install the I/O shield and DC-DC power cable (color: black/yellow) which you need to take out of the PSU package.



The listed specifications may be altered at any point in time without any pre-notice. Chieftec® is a registered trade mark. All other brands and/or logos are property of the respective owners.



2. Install the mainboard




The listed specifications may be altered at any point in time without any pre-notice. Chieftec® is a registered trade mark. All other brands and/or logos are property of the respective owners.

Arena Electronic GmbH Halskestraße 22 -26 DE-40880 Ratingen

www.chieftec.eu



3. Screw two distance holders which can be found in the accessory bag of the chassis



Distance holder for the DC-DC board



The listed specifications may be altered at any point in time without any pre-notice. Chieftec® is a registered trade mark. All other brands and/or logos are property of the respective owners.

www.chieftec.eu



4. Screw the DC-DC board on each side. After that please connect the 4PIN DC-DC power cable (color: black/yellow) with the DC-DC board



The listed specifications may be altered at any point in time without any pre-notice. Chieftec® is a registered trade mark. All other brands and/or logos are property of the respective owners.

Arena Electronic GmbH Halskestraße 22 - 26 DE-40880 Ratingen



5. Please connect the DC-DC grounding cable with the mainboard screw.




The listed specifications may be altered at any point in time without any pre-notice. Chieftec® is a registered trade mark. All other brands and/or logos are property of the respective owners.

Arena Electronic GmbH Halskestraße 22 -26 DE-40880 Ratingen



6. Please connect 24PIN power cable with the mainboard & DC-DC board.



The listed specifications may be altered at any point in time without any pre-notice. Chieftec® is a registered trade mark. All other brands and/or logos are property of the respective owners.



6. Fix the 20mm metal pins into the 4 holes of the chassis.




The listed specifications may be altered at any point in time without any pre-notice. Chieftec® is a registered trade mark. All other brands and/or logos are property of the respective owners.

Arena Electronic GmbH Halskestraße 22 -26 DE-40880 Ratingen



7. Fix 1 x 3,5 HDD and 1 x 2.5" HDD





The listed specifications may be altered at any point in time without any pre-notice. Chieftec® is a registered trade mark. All other brands and/or logos are property of the respective owners.

Arena Electronic GmbH Halskestraße 22 -26 DE-40880 Ratingen

www.chieftec.eu



8. Screw the HDD holder onto the 4 metal pins.



The listed specifications may be altered at any point in time without any pre-notice. Chieftec® is a registered trade mark. All other brands and/or logos are property of the respective owners.

Arena Electronic GmbH Halskestraße 22 -26 DE-40880 Ratingen

www.chieftec.eu



9. Close and screw the chassis. You are done.



The listed specifications may be altered at any point in time without any pre-notice. Chieftec® is a registered trade mark. All other brands and/or logos are property of the respective owners.

Arena Electronic GmbH Halskestraße 22 -26 DE-40880 Ratingen